



STREET PERFORMANCE SERIES ALIGNMENT KIT





018-05-046

213-01-376

Contents:

(4) 018-05-046 Fastener, Standard: Washer, [0.531 ID X 1.062 OD X .100 TH] (4) 213-01-376 Eyelet Parts: Spacer [0.500 ID X 0.87 OD X .30 TLG]



- 1. Install the shock eyelet on the swing arm first.
- 2. Add the necessary amount of spacers to fill the gap between the frame and upper shock eyelet as shown.
- 3. Torque all hardware to manufacturers specifications.