

STABILIZER HARDWARE INSTALLATION GUIDE



803-02-039 - PERFORMANCE SERIES Stabilizer Hardware (1-5/8 Tie Rod)

803-02-040 - PERFORMANCE SERIES Stabilizer Hardware (1-3/8 Tie Rod)



INSTRUCTIONS

USE WITH 2.0 PERFORMANCE SERIES IFP STABILIZER

Medium-strength thread-lock (blue Loctite) is recommended on all bolts.

1. Remove bushing and sleeve from shock eyelet
2. Install new bushing and sleeve included with clamp kit.
3. Position clamp on tie rod to allow full range of steering travel and suspension travel
4. Torque clamp screws to 12 ft-lb
5. Torque shock mounting bolt to 50 ft-lb



USE WITH 2.0 PERFORMANCE SERIES ATS STABILIZER

Medium-strength thread-lock (blue Loctite) is recommended on all bolts.

1. Bushing, sleeve, hex bolt, and washer included in package are not needed.
2. Disassemble clamp from stabilizer by removing bolt. Shaft must be fully extended to access bolt.
3. Assemble new clamp to stabilizer with previously removed bolt. Tighten bolt to 50 ft-lb.
4. Follow clamp positioning instructions included with ATS Steering Stabilizer.
5. Tighten clamp screws to 12 ft-lb



WARNINGS

- FOX mounting hardware are designed to fit with FOX stabilizers and allow proper clearance with the factory suspension. If aftermarket suspension components are installed it is the customers responsibility to ensure that at full cycle the suspension clears the FOX shocks.
- Proper installation and service procedures are essential for the safe and reliable installation of chassis parts, requiring the experience and tools specially designed for this purpose. Installation and maintenance procedures for this product must be performed by a qualified service technician, to avoid potentially



unsafe vehicle handling characteristics, which may result in SERIOUS INJURY or DEATH.

- Modifying your vehicle's suspension will change the handling characteristics of your vehicle. Under certain conditions, your modified vehicle may be more susceptible to loss of control or rollover, which can result in SERIOUS INJURY or DEATH.
- Any attempt to misuse, misapply, modify, or tamper with any FOX product voids any warranty and may result in SERIOUS INJURY or DEATH.



VISIT RIDEFOX.COM/TRUCK
TO FIND FOX OFFERINGS
FOR YOUR TRUCK OR SUV

2.0 PERFORMANCE SERIES IFP SHOCK

***REPLACE YOUR STOCK SHOCKS
WITH RACE-WINNING TECHNOLOGY***





RACE PERFORMANCE FOR YOUR DAILY DRIVER

HEAT-REDUCING DESIGN

- » Cold-forged, metal-impacted 6061 T6 aluminum shock body dissipates heat three times faster than a conventional steel body shock. The 2.0 Performance Series shock runs as cool as a 2.5 diameter shock on the same application.
- » FOX formulated race shock oil developed for ultimate performance at variable temperatures.

STAY INFORMED

REGISTER YOUR PRODUCT



- 1 Create your personal profile
- 2 Let us know which products you own
- 3 Receive special offers on service, upgrades, and product



RIDEFOX.COM 750 VERNON WAY SUITE 101. EL CAJON, CA 92020 USA
1.800.FOX.SHOX (369.7469) 619.768.1800 ORSERVICE@RIDEFOX.COM
PN 605-01-085 REV A APRIL 2013