



NOTE U-CUP ORIENTATION

SECTION A-A  
SCALE 4.000

CARTRIDGE ASSEMBLY

CRUSH WASHER 241-01-002-C

BOTTOM NUT 241-00-005

REBOUND KNOB 210-22-523

TORQUE:  
50±5 IN-LB

TORQUE:  
5.0±0.5 IN-LB

REFERENCE ONLY  
(FOR INSTALLATION  
INTO FORK)

018-01-007

Socket Set Half Dog Point Screw [#8-32 X 0.250 TLG]

Remote Topcap Interface Parts 820-05-272-KIT

REFERENCE ONLY  
(FOR INSTALLATION  
INTO FORK)

TORQUE:  
220±5 IN-LB

GREASE:  
LAYER OF  
BLUE MARINE

GREASE:  
THIN LAYER

019-01-088  
Set Screw [M4x4mm], SST, Cup Point, Patchlock

019-01-095  
Fastener, Standard (Metric): Screw [M3 X 6mm] SHCS, Patchlock

210-22-759  
Damping Adjust Part: Housing, Remote, 2014 FIT and O/C

210-22-819  
Damping Part: Spacer, 2014 Remote Fork

039-00-291  
Spring: Torsion 2013 Damper CTD Remote, .048 Square Wire, 0.600 Mean Coil Diam (

002-02-050  
Bearing: External [0.115 W X 0.810 OD X 0.030 TH, Ø 0.750 Bore] Turcon,Blue,Ring

036-01-044  
Seals: U-Cup, Shore 70A, 2013 CTD-ADJ, Remote Fit-CTD and Remote O/C-CTD

TORQUE:  
11±3 IN-LB

IMPORTANT:  
DO NOT ALLOW PULLEY  
TO ROTATE WHILE TORQUING

90.60.10 CABLE PULLEY

**ASSEMBLY INSTRUCTIONS:**

1. WITH THE DAMPER IN "DESCEND" POSITION INSTALL 210-22-759. POSITION HOUSING SO CABLE BOSS IS BETWEEN 1 AND 2 O'CLOCK FROM RIDER'S PERSPECTIVE.
2. INSTALL 210-22-819 OVER COMPRESSION ROD ON TOPCAP ASSY.
3. INSTALL 036-01-044 ON 210-22-760. NOTE ORIENTATION OF U-CUP.
4. INSTALL 002-02-050 ON CABLE PULLEY.
5. INSTALL 019-01-088 IN 210-22-760.
6. APPLY A LIBERAL AMOUNT OF GREASE TO 039-00-291. INSTALL SPRING TANG IN HOLE ON 210-22-760. INSTALL THIS ASSEMBLY IN HOUSING SO SET SCREW IS POSITIONED AT CABLE BOSS OF HOUSING. ENSURE SPRING TANG SEATS IN A HOLE IN BOTTOM OF HOUSING. TIGHTEN FASTENER 019-01-095 2 TO 3 TURNS.
7. LIFT UP ON HOUSING AND ROTATE COUNTER CLOCKWISE UNTIL CABLE BOSS IS AT 7 O'CLOCK FROM RIDER'S PERSPECTIVE. LOWER HOUSING AND ENSURE IT IS PROPERLY SEATED ON TOP CAP. SECURE IN PLACE BY TORQUING FASTENER 019-01-095 TO SPEC ON DRAWING.

**FOX Factory, Inc.**  
130 Hangar Way, Watsonville, CA 95076 USA  
Ph 831-768-1100  
Fax 831-768-9312

TITLE  
**2015 32 F-S FIT CTD  
Remote Cartridge Assy Complete**

SIZE DWG. NO.  
D | PLOT SCALE 1.00:1 | SHEET 1 OF 1

PROPRIETARY - PROPRIETARY INFORMATION  
THIS DOCUMENT CONTAINS CONFIDENTIAL, PROPRIETARY INFORMATION  
THAT IS FOR PROPERTY. DO NOT DISCLOSE TO OR DUPLICATE  
FOR OTHERS EXCEPT AS AUTHORIZED BY FOX.