



NOTES:

[1] APPLY THIN LAYER SLICK HONEY TO INSTALL ON AIR VALVE. APPLY THIN LAYER FLOAT FLUID ON INSTALLED AIR VALVE O-RING PRIOR TO AIR VALVE INSTALLATION.

[2] FILL INDICATED REGIONS APPROX 75% FULL WITH STA-LUBE SL3125 BLUE HI-TEMP GREASE, PAGE 2.

FOX FOX Factory, Inc. Ph 831-768-1100
 130 Hangar Way, Watsonville, CA 95076 USA Fax 831-768-9312

TITLE
 Eyelet Assy: 2017 FLOAT DPS, Nude 4, Trunnion, with Eyelet Vol Spacer

SIZE DWG. NO. **808-17-242-KIT**

PLOT SCALE 1.00:1 SHEET 1 OF 2

PROPRIETARY - THIS DOCUMENT CONTAINS CONFIDENTIAL, PROPRIETARY INFORMATION THAT IS FOX PROPERTY. DO NOT DISCLOSE TO OR DUPLICATE FOR OTHERS EXCEPT AS AUTHORIZED BY FOX.